



OLM CONVEX SIDE VIEW MIRRORS

2008-2014 WRX / STI

OLMA.70055.1-CH

OLMA.70055.1-BL



Tools Required

- Glass Cleaner
- Microfiber Towel
- 3M Double-Sided Tape (Optional)



For proper adhesion, we recommend installing the mirrors in temperatures above 60°F.

1. Clean mirror with the glass cleaner and microfiber. We recommend a cleaner with alcohol as it will strip the surface of any oils and enable the tape to stick to the surface.



2. Put an included suction cup on one of the mirrors. There are 2 that you can use if you choose to.



3. Flip the glass over and peel off the backing paper from the included double-sided tape.



4. An optional extra strip of 3M tape (not included) can be installed along the center of the mirror. Due to the curvature of the mirror, it will not have a solid connection in the center, so the extra tape can assist in keeping the mirror attached.



5. Line up the mirror and install on top of the OEM mirror by applying pressure to the 4 corners. **DO NOT PRESS ON THE CENTER OF THE MIRROR!** Since the mirror is curved, pressing on the center WILL result in breaking the mirror.



7. Repeat on the other side. Note that your field of view has changed, and this WILL make objects appear farther away compared to a flat OEM mirror. Drive with caution and enjoy your OLM mirrors!

